

BD5/MK6



OPERATING MANUAL
BEDIENERHANDBUCH
MANUEL D'UTILISATION
GEBRUIKSAANWIJZING
MANUAL DE FUNCIONAMIENTO
MANUALE DI ESERCIZIO

CONTENTS

Unpacking	2
Important	2
Introduction	2
General	2
Operation	3
Electrical Connections	3
Basic Steps	4
Positioning	4
Drainage	4
On / Off Control	4
Special Features	5
Defrost	5
Flexibility	5
Hour Meter	5
Condensate Pump	5
Low Voltage Protection	5
Dual Voltage	5
Safety	6
Service	6
Spares	6
Disposal Of Unit	6
Contacting Ebac	6
Technical Specification	7

UNPACKING

Thank you for deciding to purchase an Ebac dehumidifier. Like the many tens of thousands of people who have already bought an Ebac dehumidifier we are confident you will find it is the most effective answer to the problem of condensation and dampness related problems.

IMPORTANT

Your dehumidifier is packed in a plastic wrapping - please ensure that it is disposed of safely and where it will not be a danger to children.

INTRODUCTION


Carefully remove the BD5 dehumidifier unit from its transit box and visually check for any signs of transit damage. If there is evidence of damage DO NOT attempt to operate the unit, call your supplier for advice. Retain the packaging for further use, or dispose of it considerately.

This user manual tells you how to use the BD5 dehumidifier. Please read it thoroughly before operating the dehumidifier. If you have any questions about the unit please contact our Customer Service Department at the address shown at the back of this section or phone 01388 602751

Dehumidifiers remove moisture from the air circulating through it.

Continuous operation reduces the relative humidity of the air and this helps prevent rust, rot, mould, mildew and condensation

within the room, or other enclosed space where the dehumidifier is used.



A dehumidifier consists of a motor - compressor unit, a refrigerant condenser, an air circulating fan, a refrigerated surface, a means of collecting and disposing of the condensed moisture and a cabinet to house these components.

GENERAL

Ebac dehumidifiers can be stored and transported in the horizontal or vertical position. To operate, stand the unit upright, connect power and it is ready for operation.


When a generator is used to supply the power, it is essential to check the minimum kva required in the technical section within this manual. The generator must be started before connection is made to the dehumidifier.

OPERATION STEPS ELECTRICAL CONNECTIONS

The fan draws moist air through the refrigerated surface which cools it below its dew point, removing moisture which is collected and lead away. The cool air then passes over the hot condenser, where it is reheated. With the addition of other radiated heat the air is discharged into the room at a higher temperature but a lower relative humidity than when the air entered the unit. Continuous circulation of the room air through the dehumidifier unit gradually reduces the relative humidity in the room.

The BD5 dehumidifier is a robust, compact unit designed to control the humidity in the enclosed space in which it is placed.

The unit is thermally protected and will switch off for a period if the maximum operating temperature of 35°C is exceeded.



- WARNING -

THIS APPLIANCE MUST BE EARTHED

IMPORTANT :- The wires in the mains lead are coloured in accordance with the following code:-

GREEN & YELLOW EARTH

BLUE NEUTRAL

BROWN..... LIVE

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminal in your own plug, proceed as follows.

The wire which is coloured Green and Yellow must be connected to the terminal marked E or by the Earth Symbol or coloured Green or Green and Yellow. The wire which is coloured Blue must be connected to the terminal in the plug which is marked with the letters N or coloured Black. The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured Red.

You must safely dispose of the non rewirable plug once it has been removed from the flexible cord. It is dangerous to attempt to insert the plug into any electrical socket.

CHANGING THE FUSE

5 amp or 13 amp fuses that are ASTA approved to BS1362 should only be used.

NON REWIREABLE PLUGS

The fuse cover must be refitted after replacement of the fuse.

BASIC STEPS

Ensure that all **EXTERNAL** doors and windows are **CLOSED**. Where no doors or windows are fitted, temporarily screen off the openings.

POSITIONING

For small areas position centrally in the area to be dried. For larger areas such as open plan buildings, offices or factories, a number of dryers may be required, in such cases they should be spaced evenly around the area. Ensure that no unit is positioned in such a way that it blows directly into another.

For private houses or flats, position the dryer on one floor at a time, starting at the lowest floor, closing all internal doors on the floor previously dried. Continue until all floor levels have been dried.

Note when a particular damp patch is to be dried out the air outlet grille should be directed towards that area but should **NEVER** be closer than 1m to the surface. At no time should the inlet or outlet grilles be covered or obstructed.

DRAINAGE

Under most operating conditions water will be produced continuously and it is important that it is drained away correctly and not allowed to spill. Any spillage will evaporate and will, therefore, have to be recycled through the dryer again, which in effect, only prolongs the drying period.

PORTABLE CONTAINERS

Position a closed top container underneath the water discharge pipe (approximately 8 litres capacity). Place a short length of pipe one end over the discharge pipe and the other end in the container. Use a transparent container, this will enable you to check the level of the water and so prevent overflowing. As the unit will be running for long periods of time, a regular check should be made on the container water level.

PERMANENT DRAINAGE

Connect a flexible hose to the water discharge pipe of sufficient length so that it will reach a permanent drain. The gravity head created will allow for a gradual fall from the unit to the drain. Ensure that the hose is free of kinks and is not allowed to rise at any point above the level of the discharge point from the dehumidifier. Any air locks which may be created, should the level be raised by the hose passing over obstructions, could cause the water to "back up" the hose and spill from the dryer.

SWITCHING ON

Check the voltage selection switch is set to the correct voltage. (Dual voltage machines only)

Plug the unit into the power supply and switch on. Set the unit ON/OFF switch to the ON position.

SWITCHING OFF

Set the unit ON/OFF switch to the OFF position. Turn off the power supply and disconnect.

SPECIAL FEATURES

DEFROST OPERATION

If the ambient temperature of the room in which the dehumidifier is conditioning, falls below 15°C ice will form on the evaporator coil as the air passes over it. Over a period of time this build up of ice will effect the efficiency of the dehumidifier on it's ability to maintain the required set conditions within the room.

The BD5 is therefore fitted with a defrost control device. This defrost control device is timed to operate every 55 minutes for a period of 5 minutes.

During the defrost cycle some of the high pressure hot gas from the compressor is diverted into the evaporator coil where it melts the ice which has formed on the evaporator coil.

FLEXIBILITY

The BD5 dehumidifier unit is supplied assembled onto a trolley which is an aid to its mobility. However it is possible, by removing the four M8 bolts which fix the unit to the trolley, to have a free standing unit for longer term applications, or by mounting the unit on the wall, by means of a suitable bracket for permanent applications.

HOURLY METER

The BD5 dehumidifier is also available fitted with a hour meter. This is positioned on the control panel beneath the ON/OFF switch. This meter will measure the length of time that the dehumidifier has run. It is a non resetable type and therefore indicates the total time the unit has operated.

CONDENSATE PUMP

The BD5 dehumidifier unit can be either, factory fitted or retro fitted with a condensate pump. This condensate pump will allow :-

- The unit to run unattended, with the condensate run off to a permanent drain.
- The unit to be used up to 150ft (50metres) below the level of a permanent condensate drainage point.

LOW VOLTAGE PROTECTION

For applications which require the unit to operate under fluctuating voltage supply conditions, the BD5 dehumidifier is also available fitted with a voltage monitor. This device ensures that the compressor does not "stall start" when the supply voltage is below 208 Volts (The minimum acceptable level). Three indicators fitted to the control panel indicate the status of the dehumidifier:-


- AMBER :- Power is available to the unit
- GREEN :- Unit is running
- RED :- The voltage is below the minimum required to start the unit.

Note :- The supply voltage must be above the minimum acceptable level for a period of 3 minutes before the unit will start.

DUAL VOLTAGE MODELS

The BD5 dehumidifier unit is fitted with a transformer which will allow the unit to operate on either 110volts or 230volts 1ph 50Hz power supply.

All electrical components within the dehumidifier are rated for 110volts, for safety reasons. The voltage change over (selector switch) switch, can be found at the bottom of the coil support, internal to the unit. Remove the front cover (beneath the air inlet grille) for access.



SAFETY

- **DO NOT USE THE UNIT IF THE CABINET OR POWER CORD IS DAMAGED.**
- **DO NOT INSERT OBJECTS INTO ANY OF THE GRILLES ON THE MACHINE.**
- **DO NOT COVER OR OBSTRUCT AIRFLOW FROM THE GRILLES.**
- **DO NOT OPERATE THE UNIT WITH THE COVERS REMOVED.**
- **DO NOT ATTEMPT ANY REPAIRS SHOULD THE UNIT FAIL TO OPERATE.**
- **DO NOT STAND ON THE UNIT.**
- **DO NOT ATTEMPT TO LIFT HEAVY UNITS UN ASSISTED**
- **DO CHECK THE PLUG ON THE EQUIPMENT MATCHES THE SUPPLY.**
- **DO USE THIS UNIT ONLY FOR THE PURPOSE FOR WHICH IT WAS DESIGNED.**
- **DO ENSURE THE POWER CORD AND SUPPLY IS EARTHED CORRECTLY.**
- **DO CHECK THE VOLTAGE SELECTION BEFORE ATTEMPTING TO POWER UP THE UNIT. (DUAL VOLTAGE UNITS ONLY)**
- **DO USE A RESIDUAL CURRENT DEVICE "RCD" WHERE POSSIBLE.**

CONTACTING EBAC CUSTOMER SERVICES

If you have any further queries please contact the Ebac Customer Services Department on 01388 602751 and have the following information to hand:

- Part Number and Serial Number of the machine (located on the rating plate at the front of the machine)
- Full name and address
- Where your machine was purchased

SERVICE

This machine should be serviced by qualified Ebac personnel or other persons having technical competence in servicing refrigeration equipment following the instructions in the Ebac Service Manual.

SPARES

Full spare parts listings and Ebac Service Manuals are available upon request by contacting one of the Ebac Service Centres listed in this manual.

OZONE DEPLETION SUBSTANCE

The gas which is used inside the hermetically sealed refrigeration circuit is R22, which is an HCFC. Under NO circumstances should this gas be released into the atmosphere. The unit should be serviced by trained personnel who will re-claim the removed gas.

DISPOSAL OF UNIT

At the end of the machines working life the refrigerant must be disposed of in the correct manner.

TECHNICAL SPECIFICATION

	1026000 UK	1026100 UK	1026200 GmbH	1026300 FR	1026400 USA	Units of Measure
Height :	660	660	660	660	660	mm
Width :	440	440	440	440	440	mm
Depth :	670	670	670	670	670	mm
Weight :	51	44	44	44	44	Kg
Airflow :	375	375	375	375	375	m ³ /min
Voltage :	230	230/110	230	230	115	V
Phase :	1	1	1	1	1	
Frequency :	50	50	50	50	60	Hz
Maximum Power :	0.75	0.75	0.75	0.75	0.88	kW
Maximum Current :	4	4/8	4	4	8	A
Generator Size :	1.5	1.5	1.5	1.5	1.5	kva
Fuse Rating :	13	13	13	13	13	A
Effective Volume :	200	200	200	200	200	m ³
Refrigerant Type :	R22	R22	R22	R22	R22	
Refrigerant Quantity :	0.425	0.425	0.275	0.425	0.350	Kg
Normal Extraction :	9	9	9	9	9	l/24hrs
Maximum Extraction :	40	40	40	40	40	l/24hrs
Noise Level :	Less than 70dba when running					
Finish :	Epoxy Coated Zintec Steel					
Mobility :	Light in construction and easily positioned					
Normal :	Rated Extraction at 15°C 65% RH Conditions					
Maximum :	Rated Extraction at 45°C 99% RH Conditions					

This machine has been manufactured in the United Kingdom



Ebac Limited, St. Helen Trading Estate,
Bishop Auckland, County Durham DL14 9AL
Tel: 01388 605061 Fax: 01388 609845

Part No. 3141527 Issue 1 Dec 1995