

**EBAC LUMBER DRYER
OWNER'S MANUAL
KILN CONSTRUCTION GUIDE
TROUBLESHOOTING GUIDE
LD800**

Ebac Industrial Products
704 Middle Ground Boulevard
Newport News
VA 23606
Telephone (757) 873-6800 FAX (757) 873-3632
Website: www.ebacusa.com

EBAC LD800 TABLE OF CONTENTS

	PAGE
Warranty -----	i
Introduction -----	ii
Lumber Drying Principles -----	iii
Unpacking -----	1
Contents-----	1
KILN DESIGN & CONSTRUCTION:	
Dryer Capacities -----	2
Kiln Chamber -----	3
Lumber Stack Size -----	3
Chamber Interior Dimensions -----	4
Choosing Proper Insulation Thickness -----	5
Example Kiln Sizes -----	6
Construction of Chamber -----	7
Finishing Details of the Chamber -----	7
INSTALLATION & TESTING	
Wiring Requirement -----	13
Testing for Proper Operation -----	13
Universal Controller-----	14
Testing Two-Stage Overheat System -----	14
DRYING LUMBER:	
Preparation of the Lumber Stack -----	17
Kiln Operating Instructions -----	18
Dryer Control Settings -----	20
Additional Notes On Lumber Drying-----	21
APPENDIXES	
Oven Dry Method for Determining Equilibrium	
Moisture Content -----	22
Troubleshooting -----	24
Drawings & Specifications-----	27



Ebac

LIMITED WARRANTY

Ebac Incorporated Lumber Dryers and Controllers carry a one year limited warranty against any defect in workmanship or material. This Warranty will cover all parts and labor required to repair your Ebac Lumber Dryer or Controller. This Warranty is invalid if the unit has been abused, damaged, whether intentional or accidental, or if any modifications have been made to the unit.

In addition, an extended warranty is provided for the evaporator coil and compressor for an additional two years (three years total). Under the extended warranty a new or remanufactured part will be supplied by Ebac, provided the defective part is first returned to Ebac for inspection. The replacement part assumes the unused portion of the warranty. The extended warranty does not include labor or other costs incurred for diagnosis, repairing or removing, installing or shipping the defective or replacement parts.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IS ISSUED IN LIEU OF ALL OTHER WARRANTIES (WHETHER WRITTEN, ORAL, OR IMPLIED) INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. EBAC INCORPORATED DISCLAIMS ANY LIABILITY FOR CONSEQUENTIAL DAMAGES, LOST PROFITS, OR INCIDENTAL DAMAGES FOR BREACH OF ANY WRITTEN OR IMPLIED WARRANTY WITH RESPECT TO THE FOREGOING DESCRIBED MERCHANDISE.

Model: LD800

Serial Number: _____

Date Received: _____

Ebac Industrial Products
704 Middle Ground Boulevard
Newport News
VA 23606
Telephone (757) 873-6800 FAX (757) 873-3632
Website: www.ebacusa.com

INTRODUCTION:

You have probably never seriously considered kiln drying your own lumber before, believing it to be too expensive or too complicated to undertake on a small scale.

Prior to the introduction of the Ebac Small Scale Lumber Dryers this was true. Kiln drying was for the world of specialists: a confusing maze of kiln schedules, sampling techniques, relative humidities and complex controls – hardly inviting to the small woodworking business which merely wanted to be sure of a regular supply of quality wood at a reliable and consistent moisture content.

Ebac Small Scale Lumber Dryers have changed all that. Whether yours is a one-man business or somewhat larger, whether you are in the woodworking business or woodworking is just your hobby, you do not need any previous experience with drying. As well as being simple to install and operate, Ebac dryers are quiet and cause no pollution.

The Lumber Dryers themselves are installed in easily made chambers of the appropriate size.

This manual has been designed to guide you through the problems of choosing the correct size of wood dryer for your needs, constructing a suitable chamber and operating the kiln to obtain maximum output of wood.

Use it carefully and thoroughly and you will quickly find out everything that you need to know.

For further information and details of constructions and applications not covered, we will be pleased to offer advice and assistance as required. Please do not hesitate to contact us.

LUMBER DRYING PRINCIPLES:

When lumber is being dried, the rate of moisture evaporation is dependent on the difference between the vapor pressure of the wet wood and the vapor pressure of the air. When the vapor pressures have equalized, no further drying occurs. This is the point at which the equilibrium moisture content of the wood has been reached. (See Figure 1).


One way of increasing this vapor pressure difference and encouraging rapid drying, is to heat the wood and increase its vapor pressure. Essentially this is what conventional steam kilns do.

EMC at 68°F (20°C)

(Figure 1)

Another way of increasing the difference between the vapor pressure of the air and that of the wood is to lower the vapor pressure of the air. This is what Ebac dryers do: encourage evaporation by removing moisture from the air surrounding the wood.

As damp air is drawn into the machine (see Figure 2) water condenses onto a refrigerated coil. The water is drained off and the dried air is re-warmed with the heat from the condenser coil. The air is re-circulated through the lumber stack, causing more evaporation. Moisture-laden hot air is not simply vented into the atmosphere as in energy wasteful steam kilns; this results in efficient operation.

SIMPLIFIED SCHEMATIC DIAGRAM OF LUMBER COMPONENTS
Figure 2

Though the fastest drying is achieved at high temperature, the risks of degrade in the wood, particularly hardwood, increases at high temperature. The general rule is that the lower the temperature the better the quality.

Ebac dryers are designed to operate in the temperature range, which is the best compromise between speed and quality – about 140°F (60°C) and lower. Drying at these temperatures insures that the wood is of the highest quality, and that the equipment is reliable.

UNPACKING:

Upon receipt of your LD800, carefully inspect the shipping container and its contents for any damage. If damage is discovered, contact the Service Department for instructions.

Caution: DO NOT throw away or damage the styrofoam pieces. They will be used inside your kiln.

CONTENTS:

Your LD800 shipment consists of the following items:

1. LD800 Lumber Dryer
2. Discharge Tubing
3. Universal Controller
4. Styrofoam Baffle (2 sections)

DRYER CAPACITIES:

Table 1 below shows average drying times for the LD800. Table 2 shows the optimum load capacities for the LD800. If larger quantities than those shown in Table 2 are dried, drying speed will be proportionately slower. If small quantities are dried, the controls can be adjusted to allow for this.

Table 1 - Average Drying Time In Days *

		MOISTURE CONTENT RANGE			
FROM - TO		50% - 8%	40% - 8%	30% - 8%	20% - 8%
Type	Thickness	Days	Days	Days	Days
Hardwoods* *	1"	53	40	28	15
	2"	94	71	49	27
	3"	161	123	85	46
Softwoods	1"	16	12	8	5
	2"	35	27	19	10
	3"	56	43	30	16

* Drying times may vary depending on species, starting moisture content, thickness, and size of load.

** Drying of Claro Walnut is not recommended.

Table 2 - Optimum Lumber Capacities In Board Feet

Lumber Type	Softwoods			Hardwoods		
Thickness (Inches)	1"	2"	3"	1"	2"	3"
LD800	320	640	960	800	1600	2400

(Some capacities can be smaller or larger - consult Ebac)

Example 1: You wish to dry 4/4 Oak from a starting moisture content of 30% to 8%.

From Table 1, you see that it will take 28 days to dry 4/4 (1") hardwood for 30% to 8%.

Then from Table 2, the optimum capacity for 1" hardwood for the LD800 is 800BF. Therefore, 800 BF can be dried in about 28 days, and 10,400BF in a year. (365 ÷ 28 days = 14 loads per year x 800 BF per load).

KILN CHAMBER

LUMBER STACK SIZE:

The first step in determining your kiln chamber size is to determine the moist suitable lumber stack size (or configuration) for your purposes. This will depend primarily on the longest length board to be dried. Normally, the length of the stack will be equal to the length of the longest board. If your lumber is in short lengths (i.e.: approximately 3 feet), then the stack length should be a multiple of these shorts.

The width and height of the stack can be adjusted to suit your conditions. The “stack” may actually be made up of two or more smaller stacks, or packs.

In order to allow air-flow through the lumber stack, each “layer” must be separated from that below by a spacer or “sticker” of $\frac{3}{4}$ to 1” thickness. The air spaces thus created must be included in the overall stack height when calculating volume.

Use this procedure to determine stack height and width: First, select an appropriate width and then calculate stack height including stickers. If this calculated height would result in an awkward height to width, select a new width. See example 2 which follows.

Example 2: Desired kiln capacity is 800 BF of 1” hardwood, and the longest board is 12 feet. Add 10% to the lumber quantity to allow for non-uniformity in the stack. If that stack width is 3 feet, then each layer of lumber would contain:

$$\text{BF per layer} = 12' \times 3' \times 1" \text{ thick} = 36 \text{ BF}$$

$$\text{Layers required} = \frac{800 \text{ BF} \times 1.1}{36 \text{ BF/Layer}} = 24.4 \text{ or } 25 \text{ layers}$$

$$\text{Each Layer is } 1" + \frac{3}{4}" \text{ sticker} = 1 \frac{3}{4}" \text{ high}$$

$$\text{Stack height} = 25 \text{ layers} \times 1 \frac{3}{4}" \text{ high} = 43 \frac{3}{4}" \text{ high}$$

CHAMBER INTERIOR DIMENSIONS:

Having calculated the stack size, it is now possible to calculate the appropriate internal dimensions of the chamber. This is done by adding the required additional space around the stack for the dryer and fans as well as for good air circulation. Suggested additional space is:

Length: 16"

Width: 14"

Height: 12"

Example 3: Using information from Example 2, where stack size was 12' long and 3' wide and 43 $\frac{3}{4}$ " high, we can find required internal dimensions.

Length: 12' + 16" = 13' 4"

Width: 3' + 14" = 4' 2"

Height: 43 $\frac{3}{4}$ " + 12" = 55 $\frac{3}{4}$ "

Minimum Interior Dimensions 13'4" (L) x 4'2" (W) x 55 $\frac{3}{4}$ " (H)

CHOOSING PROPER INSULATION THICKNESS:

The wall thickness (insulation) is very important and is related to the size (surface area) of the chamber.

After adding the required internal clearances to the stack size, the internal dimensions are known, and the approximate chamber surface area can be calculated. Table 3 shows the recommended thickness of insulation (wall thickness) in relation to the total surface area of the walls, ceiling and floor of the chamber.

To determine wall (insulation) thickness we must now calculate approximate surface area of the chamber.

Example:

Kiln Dimensions: 5' x 3½' x 14' (H x W x L)

Ends: 3½' x 5' x 2 pieces = 35 sq. ft

Top and Bottom: 3½' x 14' x 2 pieces = 98 sq. ft

Front and Back: 5' x 14' x 2 pieces = 140 sq. ft

273 sq. ft surface area

From Table 3, R-11 value is appropriate. Final outside dimensions can now be determined.

Table 3 - Thickness OF Insulation

Surface Area of Chamber In Sq. Ft	100	200	300	400	500
Optimum R-Value	5	8	11	16	21

Fiberglass Insulation
R-11 = 3 1/2" R-19 = 6"

Blue Styrofoam
R-7 = 1"

The thickness in the table are optimum for year-round operation. If you wish to increase efficiency during the winter in cold climates, increase thickness by about 50% and remove extra insulation during the summer. This extra insulation may cause the kiln to overheat in the summer.

EXAMPLE KILN SIZES:

If you would rather not design the dimensions of your kiln, simply choose the best size for your operation from Table 4.

All of the kiln dimensions shown below are exterior dimensions. The load sizes refer to 1" hardwood with ¾" stickers, and all wall thickness and air spaces have been added in.

Table 4
Example Kiln Sizes
(Height x Width x Length)

6' Lumber

$$7' \times 6' \times 8' = 800 \text{ BF}$$

$$6' \times 6' \times 8' = 600 \text{ BF}$$

10' Lumber

$$5 \times 6 \times 12' = 800 \text{ BF}$$

$$5' \times 5' \times 12' = 600 \text{ BF}$$

14' Lumber

$$5' \times 5' \times 16 = 800 \text{ BF}$$

$$4\frac{1}{2}' \times 4\frac{1}{2}' \times 16 = 600 \text{ BF}$$

8' Lumber

$$6' \times 6' \times 10' = 800 \text{ BF}$$

$$5' \times 6'' \times 10' = 600 \text{ BF}$$

12' Lumber

$$5\frac{1}{2}' \times 5' \times 14' = 800 \text{ BF}$$

$$4\frac{1}{2}' \times 5' \times 14' = 2700 \text{ BF}$$

16' Lumber

$$4\frac{1}{2}' \times 5' \times 18' = 800 \text{ BF}$$

$$4' \times 5' \times 18' = 600 \text{ BF}$$

CONSTRUCTION OF CHAMBER:

The most important point is to install a continuous vapor barrier (Plastic Film) inside the frame.

The walls, floor and ceiling should be made of frame construction filled with insulation (styrofoam, fiberglass, etc.). The exterior surface should be ¼" to ½" CDX plywood. Line the interior with polyethylene film and use tape to close all gaps and cover tack heads. A good material to use over the film is ¼" tempered hardwood (exterior grade). In order to provide support for walking, ½" plywood is recommended for the floor. Use a minimum number of nails to minimize the number of holes in the plastic film. Again, put the tape over the nail heads in the hardboard. Plastic package sealing tape works well.

The LD800 kiln requires an air plenum chamber to help distribute the air throughout the lumber stack. The surface of the plenum facing the lumber stack should be 1/8" or ¼" tempered pegboard for the air to pass through.

For all dry kilns, baffles or curtains should be provided above and to the side of the stack to force the air flow through the lumber stack, not around. (Refer to Figures 4-8).

The LD800 chamber should be placed on a 4" x 4" stringers, on dry ground, preferably within a workshop or warehouse. If space limitations dictate that the chamber should be located outdoors, then it should be protected from rain, snow, and direct rays of the sun by means of a roof or separate canopy.


FINISHING DETAILS OF THE CHAMBER

When the basic construction is complete, it is necessary to bore a 2" hole in the wall adjacent to the dryer through which to pass a drain hose and the power cord(s) from the dryer.


It is very important that the hole in the wall is bored below the level of the water outlet of the dryer – otherwise water will back up in the hose and flood the interior of the chamber.

Use rope caulking or similar material to seal the hole after the hose and power cord are installed to prevent heat loss from the chamber.


LD800 Drying Chamber (Fig 4)




Lumber Stack Side View (Fig 5)




LD800 Cutout detail in Plenum (Fig 6)



LD800 End View (Fig 7)



LD800 Top View (Fig 8)



INSTALLATION AND TESTING

WIRING REQUIREMENT:

All wiring should be carried out by a competent electrical contractor in accordance with local regulations.

Check the voltage at the power supply to ensure correct voltage is 100 Volt \pm 10%, 1 Phase, 60 Hz.

The LD800 must be plugged into a suitably fused 110 Volt outlet.

TESTING FOR PROPER INSTALLATION:

Remove the left side panel by removing the four retaining screws. This will expose the evaporator coils and draintray.

<p>Warning: Do not operate the LD800 for an extended period of time with the covers removed. This will cause improper operation of the machine and may cause damage to the components.</p>

Rotate the temperature control knob and the drying control knob on the Universal Controller counterclockwise until they stop.

Attach the controller cord to the Universal Controller and latch in place.

Plug the LD800 power cord into the 110 Volt, 1 Phase, 60 Hz receptacle. (Insure that power to the receptacle has been achieved).

The fan in the LD800 will start to rotate immediately. Set the drying control to C and the temperature control knob to 45°C.

The above settings will result in the following:

1. The heating element in the LD800 will be switched on.
2. After a 10 minute delay, the compressor will start to run.

When the compressor has been running for 10 minutes, the bare copper coils above the draintray should be covered with either frost or condensation. (The last two or three turns on the rear coils may not have frost or condensation because the refrigerant is picking up superheat for the return to the compressor).

After insuring proper operation of the LD800, disconnect the power cord and reinstall the left side panel.

UNIVERSAL CONTROLLER:

The Universal Controller incorporates a two-stage overheat protection system that protects the wood from damage resulting from kiln overheat. When the kiln temperature reaches the level preset on the Universal Controller, the heating element is switched off. If the temperature continues to rise because of heat produced by the compressor, the Universal Controller will switch off the compressor. The Controller parts are (See Figure 3):

1. Cord Attachment Plug
2. Heater By-Pass Switch
3. Temperature Display
4. Temperature Setting
5. Drying Control Setting
6. Compressor Indicator Light
7. Heater Indicator Light
8. Overheat Indicator Light
9. Not Used

TESTING TWO-STAGE OVERHEAT SYSTEM:

Disconnect the power cord from the receptacle. Remove the right-hand side panel by removing the four retaining screws. This will expose the heating element and compressor.

Reconnect the power cord to the receptacle.


Warning: DO NOT reach into the electrical panel with your hand or with any tool. This may result in a severe electrical shock or death.
--

Set the drying control on the Universal Controller to C and the temperature to 45°C.


Gradually reduce the temperature control setting. When the temperature setting equals the temperature indicated by the temperature display, the heater will switch off. A further reduction of approximately 5°C will result in the compressor switching off

Should you have any problems resulting from testing your LD800 or Universal Controller, contact the Service Department for assistance.

Universal Controller (FIG 3)



Universal Controller Installation Details



DRYING LUMBER

PREPARATION OF THE LUMBER STACK:

The best lumber drying results are obtained when the loads of lumber is of the same species, quality, thickness and initial moisture content. However, this is not always possible, particularly in small scale operations. In such situations the drying procedure should follow the slowest wood in the load -- i.e., the hardest, thickest, or wettest boards.

The layers of lumber are separated by stickers. The thickness of the stickers is determined by the thickness of the lumber most commonly being dried. Stickers of $\frac{3}{4}$ " are generally used with boards up to $1\frac{1}{2}$ " thick and stickers for 1" for boards thicker than $1\frac{1}{2}$ ". In practice, one set of stickers can be used in a kiln no matter what the lumber thickness.

The layers of stickers should be placed directly above each other to prevent distortion of the boards during drying. The space between columns of stickers should be approximately 18" to 30" for board thickness up to $1\frac{1}{2}$ " and 24" to 48" for board thickness' greater than $1\frac{1}{2}$ ". Put a column of stickers at each end of the stack to support the ends and help reduce end checking. The important consideration is that the boards do not sag between rows of stickers.

Gaps in the stack cross-section are reduced by using boards of the same length, which otherwise would result in a non-uniform circulation at these spots. It is also important for good air circulation to fill the chamber to full capacity. If this is not possible, any gaps/spaces should be blocked with baffles so that air passes through the stack and not around it.

Before placing the lumber in the chamber, the initial moisture content of the wettest boards should be measured by means of an electronic moisture meter or the oven dry method (see Appendix 1). Ebac can provide a suitable moisture meter system to meet your needs at an additional cost.

KILN OPERATING INSTRUCTIONS:

1. Connect the main power cable to a suitable power supply.
2. Select the appropriate setting from the relevant drying control schedule as shown in Table 5. Settings are based on the amount and type of lumber to be dried.


Warning: If the Table calls for a setting of “C” (Continuous), set the drying control at 90% at first, until the temperature reaches 35°C (95°F). Position “C” can then be selected.

Below 35°C the dehumidifier requires the 10% off-time to defrost the ice formed on the heat exchanger (cold coil). Above 35°C (95°F), the condensation does not freeze, but drips continuously into the drain tray and out through the drainage hose.

3. Set the temperature control knob on the Universal Controller at the lower of the following:
 - A. 5°C higher than the kiln temperature (shown on the digital display on the controller); or
 - B. The maximum chamber temperature from the graph below.

The temperature should be increased by 5°C (9°F) every 24 hours, but must NEVER exceed the temperatures shown on the graph below. If the temperature does not increase in accordance with the temperature control knob adjustments, (i.e., 24 hours after an increase of 5°C the temperature has risen by a lower amount, e.g. 3°C), this indicates that the heater is operating continuously but the temperature rise has not been achieved. This can be caused by the volume of wood being heated, cold weather conditions, or inadequate insulation. The next temperature setting should be 5°C above the kiln temperature as displayed on the temperature meter.

MAXIMUM SELECTED TEMPERATURE



Two things are very important:

- A. THE RATE OF TEMPERATURE INCREASE MUST NOT BE MORE THAN 5°C (9°F) PER DAY.

Never set the thermostat more than 5°C (9°F) above the present kiln temperature. Rapid temperature increases cause the relative humidity to suddenly drop leading to surface and end checking of the lumber.

- B. THE KILN TEMPERATURE MUST NOT EXCEED THAT WHICH IS SAFE FOR THE MOISTURE CONTENT OF THE LUMBER.

The maximum chamber temperature, shown on the preceding graph, indicates the maximum safe kiln temperature at every stage of drying.

The temperature graph implies that you must measure the lumber moisture content each time before increasing the temperature when operating above 35°C (95°F). To determine if drying cycle is complete, the lumber moisture content must be actually measured using a moisture meter or the oven dry method.

4. To check that the drying rate is correct, allow the kiln about 3 days to stabilize after starting and then measure the water extracted during a 24-hour period. As the wood dries, the drying control and thermostat may be increased to maintain the water extraction rate.

COMPLETING THE RUN: When the drying cycle is complete, leave the wood for approximately 24 hours in the chamber with the Drying Control setting reduced to 10% and the thermostat reduced to its lowest setting. This will allow the residual moisture within the wood to become more evenly distributed.

TABLE 5

DRYING CONTROL SETTINGS

LD800 LUMBER DRYER

CHAMBER LOAD -- SOFT WOODS						
Drying Control Setting	4/4	25mm	8/4	50mm	12/4	75mm
	Board Ft	Cu Mtrs	Board Ft	Cu Mtrs	Board Ft	Cu Mtrs
C	320	0.8	700	1.7	1180	2.8
85	255	0.6	600	1.4	940	2.2
70	190	0.4	400	0.9	700	1.7
55	130	0.3	270	0.6	460	1.1
35	65	0.2	140	0.3	240	0.6

CHAMBER LOAD -- HARD WOODS						
Drying Control Setting	4/4	25mm	8/4	50mm	12/4	75mm
	Board Ft	Cu Mtrs	Board Ft	Cu Mtrs	Board Ft	Cu Mtrs
C	800	1.9	1750	4.1	2900	6.8
85	640	1.5	1400	3.3	2300	5.4
70	510	1.2	1050	2.5	1750	4.1
55	320	0.8	700	1.7	1150	2.7
35	160	0.4	350	0.8	550	1.3

The above control settings will produce dried wood of good quality, higher than recommended settings can be used to give quicker drying if required. This may result in instances of degrade. If you are in any doubt select only the recommended setting.

ADDITIONAL NOTES ON LUMBER DRYING

As the wood dries, the daily volume of water extracted may decrease. The drying control setting may be increased to compensate for this fall-off in order to achieve a constant daily extraction of water.

When drying a mixture of thickness and/or species of wood, adjust the drying control to the setting applicable for the total load of wood as if it were comprised of the thickness or species requiring the lowest setting. e.g., a mixture of:

320 BF of 1" Oak and

240 BF of 3" Spruce

560 BF (320 + 245) of 1" Oak requires a setting of 70%

560 BF of 3" Spruce requires a setting of 55%

Therefore the correct setting for the mixed load is 55%

To prevent overheating during hot weather conditions, particularly if the drying chamber has been very well insulated, water extraction may occasionally be suspended to enable the chamber to cool. This is not a fault condition, however it is an indication that the chamber walls incorporate excessive insulation. This situation can be diagnosed by observing intermittent water extraction when the drying control is set to "C".

In accordance with International practices, temperatures in these instructions are expressed in degrees centigrade (Celsius). The following scale can be used to determine the equivalent temperature in Fahrenheit.

<u>°C</u>	<u>25</u>	<u>30</u>	<u>35</u>	<u>40</u>	<u>45</u>	<u>50</u>	<u>CENTIGRADE</u>
°F	77	86	95	104	113	122	FAHRENHEIT

APPENDIX 1

OVEN DRY METHOD FOR DETERMINING EQUILIBRIUM MOISTURE CONTENT:

If an accurate moisture meter is not available, then moisture content can be determined using the oven dry method. The oven dry method is actually more accurate than moisture meters, but not very convenient. You do need an accurate scale for weighing the wood samples and an oven (a baking oven will do) to bake the samples.

Select a plank from the wood to be dried and cut 6 inches from each end and discard these cutoffs. (They will be much drier than the rest of the piece). Cut several one-inch pieces from one end until you have about a pound of weight. Weigh these and record the wet weight. Weigh the remaining portion of the plank and add it to the middle of the lumber stack in the kiln where it can be retrieved periodically to monitor equilibrium.

Place the 1" sample in a 225°F oven for 24 to 36 hours, then weigh again. This is the oven dry weight. Use the formula below to calculate the starting EMC of the sample.

$$\text{EMC} = \frac{\text{Wet Weight} - \text{Dry Weight}}{\text{Dry Weight}} \times 100\%$$

The moisture content of the lumber in the stack can now easily be monitored by periodically pulling the sample plank from the stack and weighing it. First, however, calculate the future dry weight of the plank by using the EMC just calculated.

$$\text{Plank Dry Weight} = \frac{\text{Wet Weight}}{1 + \frac{\text{EMC}}{100}}$$

Now having calculated the plank dry weight, use the formula above for determining EMC to monitor drying progress.

Example: You have weighed your 1" samples and they weigh 1.35 lbs. The remaining plank weighs 15.4 lbs and is added to the lumber stack in the kiln and the dryer can be turned on. After drying the samples 36 hours in an oven, you weigh them and the weight is 0.94 lb.

$$\text{Starting EMC} = \frac{1.35 \text{ lb.} - 0.94 \text{ lb.}}{0.94 \text{ lb.}} \times 100 = 44\%$$

Now calculate the future dry weight of the plank in the kiln:

$$\text{Plank Dry Weight} = \frac{15.4}{1 + \frac{44}{100}} = 10.7 \text{ lb.}$$

After a few weeks of drying, the plank is removed from the stack and weighs 12.2 lb.,

$$\text{Starting EMC} = \frac{12.2 \text{ lb.} - 10.7 \text{ lb.}}{10.7 \text{ lb.}} \times 100 = 14\%$$

APPENDIX II

TROUBLESHOOTING:

In case of trouble, first check that all instructions in the manual have been carefully followed. Next, go through the following chart. If the problem is still not resolved, call Ebac Incorporated. In most cases, a simple phone call will resolve the question.

SYSTEM OVERVIEW:

Air is drawn into the dryer where the moisture is extracted from it. Moisture is extracted when the air is passed through the evaporator coil. This coil is cooled to a temperature lower than the dew point temperature of the air and hence condensation forms on it. The dryer consists of 7 parts:

1. Fan motor to draw the air through the unit.
2. Compressor which drives the refrigeration circuit.
3. Evaporator coil – cold section of the refrigeration circuit.
4. Condenser coil – hot section of the refrigeration circuit.
5. Capillary tube – separates the hot and cold section of the refrigeration circuit with regard to gas flow.
6. Auxiliary heater.

The Universal Controller controls the power to the dryer and controls the amount of water to be extracted by operating the compressor in accordance with the drying control setting, i.e.: a 25% setting will run the compressor for 15 minutes in each hour. The fan runs continuously regardless of the drying control setting. The auxiliary heater runs only when the thermostat setting is greater than the kiln temperature, once the desired temperature is achieved, the heater shuts off.

<u>Symptoms</u>	<u>Possible Fault</u>
Unit completely Inoperative	1. <u>No power at receptacle.</u> Check fuse, etc., feeding receptacle.
Normal Operation but Low Water Extraction Kiln Temperature above 95°F (35°C)	1. <u>Normal Start-Up.</u> It usually takes 3 to 4 days for a new load of lumber to stabilize and for water output to reach normal levels. 2. <u>Dry Lumber.</u> As the moisture content of the lumber drops below about 10%, you will notice a drop in water extraction. If not at continuous, the timer may be advanced to maintain rate, but the moisture content of the lumber should be checked at this point to avoid over-drying. 3. <u>Compressor Overheating.</u> If the kiln temperature is over rating for unit, thermal circuit breaker in compressor may be opening. Reduce temperature by removing insulation, or lowering drying control setting. Do Not lower thermostat setting. 4. <u>Refrigerant Gas Loss From Circuit.</u> A refrigeration loss can be recognized by operating unit outside the kiln and check for severe freezing of a small proportion, less than half of the evaporator coil (cold coil) at temperatures above 68°F and relative humidity above 30%. Normally the coil freezes evenly. 5. <u>Blocked or Frozen Drain Hose.</u> Water may be flooding kiln.
Normal Operation But Low Water Extraction Kiln temperature Below 95°F (35°C)	1. IF drying control knob is set at continuous, coils may be icing up. Set back to 90% until temperature rises above 95°F (35°C). 2. At temperatures below about 95°F (35°C), lumber is slow to give up its moisture. Raise kiln temperature to maintain drying speed.

<u>Symptoms</u>	<u>Possible Fault</u>
Low Kiln Temperature Normal Water Extraction	<ol style="list-style-type: none"> 1. As long as water extraction is normal, kiln temperature cannot be too low. In fact, the lower the temperature the better the wood quality. The insulation thickness' in Table 1 provides for 50°F (28°C) temperature rise over outside temperature at continuous drying control setting. Lower settings will give lower temperature rise.
Mold or Mildew on Lumber	<ol style="list-style-type: none"> 1. This condition is not harmful to the lumber, but can be minimized with improved airflow or higher kiln temperature.
Bottom Layer or Two of Lumber Not Dry	<ol style="list-style-type: none"> 1. This is caused by large temperature differences (greater than 5°F) from top to bottom of the kiln. Greater airflow or a better door seal will usually improve this.
Temperature in Kiln Continues to Rise Above Thermostat Setting.	<p>** DO NOT LOWER THERMOSTAT SETTING **</p> <ol style="list-style-type: none"> 1. Thermometer on controller may need to be adjusted. If extraction maintains a normal rate, check temperature in kiln with another thermometer at the base of the dryer. If the temperature reads lower or higher than the thermometer needle on the controller, call Ebac for adjustment procedure. 2. If temperature reads the same and extraction ceases or slows substantially, you may have a "temporary over-insulation situation". Simply peel back a corner of insulation from the top of your kiln chamber. If this does not remedy the situation in 24 hours, call Ebac.

APPENDIX III

DRAWINGS AND SPECIFICATIONS


LD800 SPECIFICATIONS

Height:	24"
Width:	13 ½"
Depth:	22"
Weight:	82 lbs
Airflow:	460 CFM
Power Rating (Dryer):	320 W (Max)
Power Rating (Heater):	350 W (Operates Intermittently)
Power Supply:	115v, 60Hz, 7 Amps
Maximum Operating Temperature:	45°C (113°F)
Finish:	Epoxy/Vinyl Coated Steel
Refrigerant Type:	R134-A
Refrigerant Charge:	7.25 oz.
Special Features:	<ol style="list-style-type: none">1. Stainless Steel Water Collection Tray For Corrosion Resistance2. Powerful centrifugal fan for even airflow.

SPARE PARTS LIST LD800

	DESCRIPTION	EBAC PART NO.	QUANTITY
1.	Drain Tray	2830107	1
2.	Evaporator Coil	2830108	1
3.	Condenser Coil	2830117	1
4.	Compressor	3820901	1
5.	Filter Dryer	3820901	1
6.	Fan Motor	2830118	1

ISSUE	DATE	AMENDMENTS
1	11/02/99	ORIGINAL
2	11/10/01	MODIFIED WIRING - VDA



Edgarc LIMITED BRISTOL AUCKLAND ENGLAND

1993

3RD ANGLE PROJECTION
DO NOT SCALE
IF IN DOUBT ASK

DIMENSIONS IN mm
TOLERANCES UNLESS OTHERWISE STATED
0 ± 0.25
0.00 ± 0.05
ANGULAR ± 0.5 DEGREE

TITLE: LD800 WIRING DIAGRAM

MATERIAL: _____

FINISH: _____

DRAWN: MICHAEL DUNN

CAD SCALE: _____

DRAWN: 5010275

SHEET 1 OF 1

UC2 SPECIFICATIONS


Height:	9 ½"
Width:	11 ½"
Depth:	6"
Weight:	2.2 lbs
Power Supply:	115V, 60Hz
Outputs:	Heat Compressor
Display:	2 Digit 0.8" LED
Display Resolution:	1°C
Special Features:	<ol style="list-style-type: none">1. Stage Overheat Protection.2. Heat Disable Switch

SPARE PARTS LIST UC2

	DESCRIPTION	EBAC PART NO.	QUANTITY
1.	Universal Controller Housing	3250804	1
2.	Housing	3033812	1
3.	Male Insert	3033809	1
4.	1 mm Plug Contacts	3033814	7
5.	Power Supply PCB	1611300	1
6.	Display PCB	1611200	1
7.	Temperature Sensor	1350801	1
8.	Interconnecting Lead	1350802	1
9.	Knobs	3090611	2


TEMPERATURE SENSOR SPECIFICATIONS

Temperature Sensor:	LM35DZ
Sensor Output	10 MV / °C
Supply Voltage:	120V DC



Ebac Ltd Part No. 2611201
MOD 1123456789

MATERIAL	FINISH	TOLERANCE UNLESS STATED	ISS	1					
		DIMENSIONS IN m.m.	DATE	2/99					
SCALE			C/N						
DRAWN			SECURITY CLASSIFICATION						
CHECKED	TITLE		INSPECTION PROCEDURE						
APPROVED			DRG. NO.						
	UCC2 DISPLAY SILK SCREEN			5029004					A 4



Note:-
LED'S To Be Fitted Flush With Pcb
IC5 IC6 SMT LED1 To LED4
All To Be Fitted To Track Side Of Pcb
IC5 and IC6 to be mounted flush to the pcb

MASTER COPY

DRAWN BY	SKR/LLV	ISS.	1	2	3	4	EBAC LTD	SECURITY CLASSIFICATION
CHECKED	<i>[Signature]</i>	DATE	19-10-88	05-12-90	08-03-91	19-03-92	Universal	DRAWING NO. 5026056
INSPECTION PROCEDURE	<i>[Signature]</i>	C/N				3391	Controller	